Technical Data Sheet

KEMPEROL® 2K-PUR



SYSTEM

Work Pack includes: Component A: Beige Formulation, Component B: Brown Formulation

| Product Description | KEMPEROL® 2K-PUR is a two-component, UV-stable, "odor-free," solvent free, Low VOC, high performance cold liquid-applied waterproofing and roofing resin. |
|-------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | KEMPEROL [®] 2K-PUR reinforced membrane system can be surfaced with traffic coatings, reflective coatings, aggregate surfacing coatings and other granular materials to achieve a desired function and appearance. |
| Composition & Materials | A monolithic membrane is created in the field by combining the KEMPEROL [®] 2K-PUR two-part, cold liquid-applied reactive-cure polyurethane resin with KEMPEROL [®] polyester reinforcing fleece. |
| Use | KEMPEROL [®] 2K-PUR membrane is suitable for a wide range of interior and exterior applications including roofs, plazas, balconies, terraces, planters, foundations, mechanical rooms, water features, and other waterproofing applications. |
| | Interior or exterior applications of KEMPEROL [®] 2K-PUR membrane exposed to UV-light may yellow or discolor. Use of a coating or aggregate surfacing systems are recommended where colorfast applications are required. |
| Limitations | KEMPEROL [®] 2K-PUR may be applied when the ambient temperature is 41 °F (5 °C) and rising, and the substrate temperature is a minimum of 5 degrees above the dew point. The maximum application temperature is approximately 90 °F (32 °C). Note: Viscosity increases with falling temperature. For temperatures below 50 °F (10 °C), KEMPEROL [®] A 2K-PUR Accelerator should be added to component A to reduce set time. |
| Yield | KEMPEROL® 165 Fleece:38 ft² (3.53 m²) per 12.5 kg work pack.KEMPEROL® 120 Fleece:45 ft² (4.20 m²) per 12.5 kg work pack.Note: All yields are approximate and may vary depending upon smoothness and absorbency of substrate. |
| Storage | Always store in cool and dry location. Do not store in direct sunlight or in temperatures below 50 °F (10 °C) or above 80 °F (27 °C). Approximate shelf life 12 months with proper storage. |
| Precautions | For best use, 24 hours before application, the material is to be acclimated at temperatures between 65-70 °F (18-21 °C). |
| | Review Safety Data Sheets before handling, available online at www.kempersystem.net. |
| Surface Preparation | All surfaces must be free from gross irregularities, loose, unsound or foreign material such as dirt, ice, snow, water, grease, oil, release agents, lacquers, or any other condition that would be detrimental to adhesion of the primer and membrane. This requires careful preparation of |
| Priming | existing horizontal and vertical substrates; cracks are filled, expansion joints are prepared, flashings are removed or modified, and termination points are determined. Substrates and penetrations are prepared to rigorous industry standards, and may require scarifying, sandblasting or grinding in some cases to achieve a suitable substrate. |
| | After substrate preparation, temporary watertightness may be achieved with the application of KEMPERTEC® D Primer or EP Primer and Joint Sealant. Alternatively, the use of quick-cure KEMPERTEC® R or EP5 Primer may allow same-day membrane application. Refer to the appropriate KEMPERTEC® primer technical data sheet for application instructions. |
| | Headquarters: Kemper System America, Inc. 1200 North America Drive West Seneca, NY 14224 |

Headquarters: **Kemper System America, Inc.** | 1200 North America Drive | West Seneca, NY 14224 Customer/Technical Service: Phone (800) 541-5455 | Fax (716) 558-2967 | inquiry@kempersystem.net

| | Sustainability | Information | | prane Prope | |
|-----------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | Bio-Based Material | 0.0 % | Physical Property | Test | Value |
| | Recycled Content % (post / pre | | | Method | |
| | Manufacture Location | Buffalo, NY, USA | Color Physical State | | Yellow-Gray |
| | | | | | Cures to Solid |
| | Allow primer to cure | completely prior to | Thickness (165 Fleece) VOC Content | D5147 | 80 mils |
| | | application of the KEMPEROL [®] membrane. | | | 6 g/l |
| | | Note: Prior to opening the containers of | | D5147 | >70 lbf/in |
| | KEMPEROL [®] 2K-PUR Resi | | Elongation | D5147 | Min 30% |
| | | | Tearing Strength | D5147 | 90 lbf |
| | | Puncture Resistance | D5602 | 56 lbs. | |
| | | | Dimensional Stability | D1204 | 0.15% |
| ing of Posin | Stop 1. Mix racin | Component A (baiga | Water Absorption | D570 | < 1% |
| xing of Resin | Step 1: Mix resin | Impact Resistance Water Vapor Transmission | D2240 E96 | Shore A:75 +/- 5 | |
| | | formulation) with a spiral agitator until the liquid | | | 0.08 Perms |
| | is a uniform cream color. | | Crack Spanning Short-Term Temperature | | 2 mm/0.08 inch |
| | | | | | 250 °C / 482 °F |
| | Step 2: If the ambient te | Step 2: If the ambient temperature is below 50°F | | | 30 minutes |
| | | (10°C), A2K-PUR Accelerator, a cold weather additive, should be mixed into the Component A. | | | 2 hours |
| | | | | | 24 hours |
| | The accelerator should be | | Solid To Walk On After* Can Be Driven On After* | | 48 hours |
| | | | Apply Coating/Surfacing | | 16-48 hours |
| | agitator for 2 minutes of | or until both liquids are | After* | | |
| | thoroughly blended. | | Apply Overburden After* | | 48 hours |
| | Step 3: Add hardener | | Completely Hardened* | | 3 days |
| | NOTE: DO NOT break of Step 1: After the Resin is evenly onto the surface in Step 2: Roll the KEMPER | mixed, using a KEMPER n even stroke; covering o | DL® roller nap or brush, an ne working area at a time | oply 1/2 of th e, between 10 | ie resin liberally a) - 15 ft². |
| | Step 1: After the Resin is evenly onto the surface in Step 2: Roll the KEMPER (natural unrolling procedure fleece, saturating from the white spots. White spots these areas before proceded step 3: Apply the remain coat of resin onto the fleece all excess should be rolled | mixed, using a KEMPERG of even stroke; covering of ROL® Fleece directly into ure), avoiding folds and we be bottom up. The appea are indications of unsatu- eding. ing 1/2 of the resin to the ece should result in a glos of forward to the unsatura | DL [®] roller nap or brush, and the working area at a time the resin, making sure t vrinkles. Use the roller or rance of the fleece should rated fleece or lack of ac e top of fleece to complet sy appearance. The fleece ted portion of the fleece | oply 1/2 of the, between 10 he SMOOTH brush to word d be opaque y thesion. It is in the can only hold . The correct a | e resin liberally a) - 15 ft ² . SIDE IS FACING k the resin into t yellow/gray with mportant to corr on. Rolling the fi d so much resin a amount of resin v |
| facing | Step 1: After the Resin is evenly onto the surface in Step 2: Roll the KEMPEF (natural unrolling procedure fleece, saturating from the white spots. White spots these areas before proceded step 3: Apply the remain coat of resin onto the fleece. | mixed, using a KEMPERG n even stroke; covering o ROL® Fleece directly into ure), avoiding folds and v the bottom up. The appeat are indications of unsatu- eding. ing 1/2 of the resin to the ce should result in a glos d forward to the unsatura- eece with no dry fleece vi- tions, and transitions. Alv nbrane accepts a wide vi- al wear. The KEMPEROL® to ensure proper bond | DL [®] roller nap or brush, ap the working area at a time the resin, making sure t vrinkles. Use the roller or rance of the fleece should rated fleece or lack of ac e top of fleece to complet sy appearance. The fleece ted portion of the fleece sible. Work wet membrar vays assure full resin satu ariety of KEMPERDUR [®] to 2K-PUR membrane mus petween the membrane | oply 1/2 of the between 10 be SMOOTH brush to word be opaque y thesion. It is in the the saturation of the correct a the to avoid any ration of fleece pcoats and ag | e resin liberally a) - 15 ft ² . SIDE IS FACING k the resin into the yellow/gray with mportant to corresin on. Rolling the find amount of resin within the population of the so much resin and amount of resin within the ggregate surfaction within 16-48 ho |
| 5 Fleece) | Step 1: After the Resin is evenly onto the surface in Step 2: Roll the KEMPEF (natural unrolling procedu fleece, saturating from the white spots. White spots these areas before proceed Step 3: Apply the remain coat of resin onto the flee all excess should be rolled completely saturate the flor lifting at corners, junct KEMPEROL® 2K-PUR Mer for aesthetic or mechanic of membrane application | mixed, using a KEMPERG of even stroke; covering of ROL® Fleece directly into ure), avoiding folds and we be bottom up. The appead are indications of unsatu- eding. ing 1/2 of the resin to the ece should result in a gloss of forward to the unsaturated forward to the unsaturated ece with no dry fleece with ions, and transitions. Alw mbrane accepts a wide we al wear. The KEMPEROL® to ensure proper bond vill require surface abrasi be disposed of in standa -PUR resin must be hand | DL [®] roller nap or brush, and the working area at a time the resin, making sure t vrinkles. Use the roller or rance of the fleece should rated fleece or lack of ac e top of fleece to complet sy appearance. The fleece sible. Work wet membrane vays assure full resin satu ariety of KEMPERDUR [®] to 2K-PUR membrane mus between the membrane on. | oply 1/2 of the between 10 he SMOOTH brush to wor d be opaque y thesion. It is in the to avoid any ration of fleed pcoats and act t be surfaced and surfacing | e resin liberally a) - 15 ft ² . SIDE IS FACING k the resin into the yellow/gray with mportant to correct on. Rolling the find amount of resin to y blisters, openin te. ggregate surfacire within 16-48 ho . After the 48 ho oroughly mixing |
| Fleece) acing osal ering | Step 1: After the Resin is evenly onto the surface in Step 2: Roll the KEMPEF (natural unrolling procedu fleece, saturating from the white spots. White spots these areas before proceed Step 3: Apply the remain coat of resin onto the flee all excess should be rolled completely saturate the flor lifting at corners, junct KEMPEROL® 2K-PUR Mer for aesthetic or mechanic of membrane application window the membrane v Cured 2K-PUR resin may components. Uncured 2K not throw uncured resin at KEMPEROL® 2K-PUR work | mixed, using a KEMPERG of even stroke; covering of ROL® Fleece directly into ure), avoiding folds and we bottom up. The appeat are indications of unsatu- eding. ing 1/2 of the resin to the ece should result in a glos of forward to the unsatura- eece with no dry fleece with ions, and transitions. Alw mbrane accepts a wide we al wear. The KEMPEROL® to ensure proper bond will require surface abrasi be disposed of in standa way. | DL [®] roller nap or brush, and the working area at a time the resin, making sure t vrinkles. Use the roller or rance of the fleece should rated fleece or lack of ac e top of fleece to complet sy appearance. The fleece sible. Work wet membrane vays assure full resin satu ariety of KEMPERDUR [®] to 2K-PUR membrane mus between the membrane on. | oply 1/2 of the between 10 he SMOOTH brush to wor d be opaque y thesion. It is in the to avoid any ration of fleed pcoats and act t be surfaced and surfacing | e resin liberally a) - 15 ft ² . SIDE IS FACING k the resin into the yellow/gray with mportant to correct on. Rolling the find amount of resin to y blisters, openin te. ggregate surfacire within 16-48 ho . After the 48 ho oroughly mixing |
| ā Fleece) | Step 1: After the Resin is evenly onto the surface in Step 2: Roll the KEMPEF (natural unrolling proced) fleece, saturating from the white spots. White spots these areas before proceed Step 3: Apply the remain coat of resin onto the flee all excess should be rolled completely saturate the fl or lifting at corners, junct KEMPEROL® 2K-PUR Merr for aesthetic or mechanic of membrane application window the membrane v Cured 2K-PUR resin may components. Uncured 2K not throw uncured resin and the second se | mixed, using a KEMPERG of even stroke; covering of ROL® Fleece directly into ure), avoiding folds and we bottom up. The appead are indications of unsatu- eding. ing 1/2 of the resin to the ece should result in a glos of forward to the unsaturate eece with no dry fleece vi- ions, and transitions. Alw mbrane accepts a wide vi- tal wear. The KEMPEROL® to ensure proper bond vill require surface abrasi be disposed of in standa -PUR resin must be hand way. | DL [®] roller nap or brush, ap the working area at a time the resin, making sure t vrinkles. Use the roller or rance of the fleece should rated fleece or lack of ac e top of fleece to complet sy appearance. The fleece ited portion of the fleece sible. Work wet membrar vays assure full resin satu ariety of KEMPERDUR [®] to 2 X-PUR membrane mus between the membrane on. | oply 1/2 of the between 10 he SMOOTH brush to wor d be opaque y thesion. It is in the to avoid any ration of fleed pcoats and act t be surfaced and surfacing | e resin liberally a) - 15 ft ² . SIDE IS FACING k the resin into the yellow/gray with mportant to correct on. Rolling the find amount of resin to y blisters, openin te. ggregate surfacire within 16-48 ho . After the 48 ho oroughly mixing |
| Fleece) acing osal | Step 1: After the Resin is evenly onto the surface in Step 2: Roll the KEMPEF (natural unrolling procedu fleece, saturating from the white spots. White spots these areas before proceed Step 3: Apply the remain coat of resin onto the flee all excess should be rolled completely saturate the fl or lifting at corners, junct KEMPEROL® 2K-PUR Mer for aesthetic or mechanic of membrane application window the membrane v Cured 2K-PUR resin may components. Uncured 2K not throw uncured resin at KEMPEROL® 2K-PUR work item#: | mixed, using a KEMPERG of even stroke; covering of ROL® Fleece directly into ure), avoiding folds and we bottom up. The appead are indications of unsatu- eding. ing 1/2 of the resin to the ece should result in a glos d forward to the unsatura- eece with no dry fleece wi ions, and transitions. Alw mbrane accepts a wide we al wear. The KEMPEROL® to ensure proper bond will require surface abrasi be disposed of in standa -PUR resin must be hand way. c pack: Size: | DL [®] roller nap or brush, ap the working area at a time the resin, making sure t vrinkles. Use the roller or rance of the fleece should rated fleece or lack of ac e top of fleece to complet sy appearance. The fleece tied portion of the fleece sible. Work wet membrar vays assure full resin satu ariety of KEMPERDUR [®] to 2K-PUR membrane mus between the membrane on. | oply 1/2 of the between 10 he SMOOTH brush to wor d be opaque y thesion. It is in the to avoid any ration of fleed pcoats and act t be surfaced and surfacing | e resin liberally a) - 15 ft ² . SIDE IS FACING k the resin into the yellow/gray with mportant to correct on. Rolling the find amount of resin to y blisters, openin te. ggregate surfacire within 16-48 ho . After the 48 ho oroughly mixing |